

Item No. :
RSN-500A
RS-01
RS-02

Unit : (CM)

Parts \ Size	XS	S	M	MT	L	XL	XL-1	2XL	2XL-1	3XL	4XL	5XL	6XL
A.CHEST:Circumference at Armpits tolerance± 1.25 CM	101	106	109	114	119	123	127	131	136	142	152	163	173
B.WAIST:Stretched circumference at middle of belt stretched tolerance± 1.25 CM	83	89	91	96	101	105	111	116	121	127	148	158	168
C.HIPS:Circumference measured 9" below center of belt tolerance± 1.25 CM	100	101	105	108	111	115	119	123	129	133	145	158	168
D.THIGH:Leg circumference measured 3" below crotch seam tolerance± 1 CM	57	59	61	64	65	68	70	72	73	76	81	87	90
E.COLLAR:Length of collar measured along top from end to end tolerance± 1 CM	43	45	48	49	51	52	53	55	56	58	59	62	65
F.SLEEVE:Shoulder point to end of sleeve (NO rib) tolerance± 1 CM	51	54	57	59	60	61	63	65	69	69	73	74	76
G.ARM Hole:Length of seam around arm cap at suit body tolerance± 1 CM	51	53	54	55	55	60	61	63	63	65	68	70	72
H.MID-FOREARM:Circumference of sleeve 3" above sewn cuff tolerance± 1 CM	32	32	34	35	37	39	39	40	40	42	45	47	49
I.FT NECK TO WAIST:Side neck point to middle of belt tolerance± 1 CM	49	50	53	54	55	57	58	59	59	60	66	69	72

J.BACK NECK TO WAIST:From bottom of collar to middle of belt tolerance± 1 CM	49	50	51	52	54	56	57	58	58	59	65	67	70
K.WAIST TO END OF LEG:Middle of belt to the end of leg tolerance± 1.25 CM	100	101	102	103	104	104	105	107	108	109	110	115	119
L.INSEAM:Center of crotch seam along inside to the end of leg tolerance± 1.25 CM	76	76	77	77	77	77	78	80	80	80	82	87	89
M.CROTCH:Front waist through legs to middle of back belt tolerance± 1 CM	61	64	64	65	66	66	68	69	70	70	70	76	80
N.MID-CALF:Circumference of leg 3" above sewn cuff tolerance± 1 CM	35	38	40	43	45	46	47	48	49	50	53	55	57
Q.SHOULDER:Back Width tolerance± 1 CM	44	45	49	50	52	53	54	55	57	58	61	65	69
Zipper length(inch) :	22.5"	22.5"	24"	25"	25"	26"	27"	27"	27.5"	27.5"	28.5"	30"	

